

Quick Start Guide – 3010a Programmable Frequency Divider and Clock Source

Your 3010a Programmable Frequency Divider module is ready to go. Apply 5~6Vdc with the dc cable provided and the input signal you want to divide. The jumpers have been preset to provide **divide-by-12 on all outputs**. You can change your divider settings by moving the 2mm jumpers provided. It is not necessary to power off the divider module when changing jumper settings.

Divider **programming table**:

MSB (4)	LSB (1)	divide by	duty cycle
0	0	1	direct
0	1	2	50
0	2	3	33
0	3	4	50
1	0	5	50
1	1	6	50
1	2	8	50
1	3	9	44
2	0	10	50
2	1	12	50
2	2	15	47
2	3	16	50
3	0	18	50
3	1	24	50
3	2	30	50
3	3	32	50

Note that this table applies to all three dividers. The divide-by-1 function allows the divider to act as a **buffer amplifier**. The input signal level can be from typically less than -30dBm to a maximum of +13dBm.

When power is applied, the green PWR LED will be illuminated (above the O in Valon). If a valid input signal is present, the blue Activity LED will be visible in the location shown.

Divider 3 output is available on the 10-pin 2mm header. Pin 9 is Divider 3 OUT. Pin 1,3,5, and 7 are the Divider 3 output with an additional divide by 16,8,4, and 2.

More information can be found on our website under **3010A Specifications**:
<https://www.valonrf.com/frequency-divider-2ghz.html>

